

## **Air Purifier**

Instruction Manual



ATP 6100 I

ΕN

#### Please read this user manual first!

Dear Valued Customer,

Thank you for preferring this Beko appliance. We hope that you get the best results from your appliance which has been manufactured with high quality and state-of-the-art technology. For this reason, please read this entire user manual and all other accompanying documents carefully before using the appliance and keep it as a reference for future use. If you handover the appliance to someone else, give the user manual as well. Follow the instructions by paying attention to all the information and warnings in the user manual.

Remember that this user manual may also apply to other models. Differences between models are explicitly described in the manual.

#### Meanings of the Symbols

Following symbols are used in various sections of this user manual:



Important information and useful hints about usage.



**WARNING:** Warnings against dangerous situations concerning the security of life and property.



This appliance has been manufactured in environmentally friendly modern plants without giving any harm to the nature.

## **CONTENTS**

#### 1 Important Safety and Environmental

Instructions	4-7			
1.1 General Safety				
2 How The Air Purifier Wo	rks 8			
3 Know Your Air Purifier	8			
4 Control Panel Introduction	on 9			
5 Operating Instructions	10			
5.1 important notes	10			
6 Controls Introduction	10			
7 To Operate Your Air Puri	fier 11			
8 Change The Hepa Filter	12			
9 Troubleshooting	12			
10 Technical Data	13			

## **Important Safety and Environmental Instructions**



**NOTE:** Before reading these instructions, please view the corresponding illustrations. (fig.1/Page7)



**NOTE:** With proper care and use, this air purifier will give you fresh, clean air for many years.

#### 1.1 General Safety

- Check if the voltage indicated on the appliance corresponding to the local mains voltage before you connect the appliance.
- To avoid fire hazard, never put the cord under rugs, or near any heat source.
- Carefully discard any plastic wrapping that was used for the packaging.
- Do not use the air purifier outside.
- Do not place the unit near any heat source or in direct sunlight.
- Always unplug the air purifier before removing the grill, changing the filters, cleaning the air purifier or whenever it is not in use.
- Do not use in or around water or any other liquids. Do not attempt to wash the unit under running water.
- Use appliance only for intended household use as described in this manual.
- Ensure that all air openings are

- not restricted or covered in any way.
- Do not place anything on top of the unit.
- Never insert any object into any openings.
- Do not use the air purifier if any part is missing or damaged in any way.
- Do not attempt to repair or adjust any mechanical functions of this unit. If the unit becomes damaged call the service number on the back of this manual.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The air purifier contains no user serviceable parts and should the product suffer damage or breakdown call the service number on the back of this manual.
- Should the air purifier stop working, first check the fuse/circuit breaker at the distribution board is operating, before contacting the place of purchase.
- This appliance is not intended for use by persons (including children) with reduced physical, sen-

## **Important Safety and Environmental Instructions**

sory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- This appliance is intended to be used in household and similar applications such as:
  - Staff kitchen areas in shops, offices and other working environments;
  - Farm houses;
  - By clients in hotels, motels and other residential type environments;

- Bed and breakfast type environments.
- Save these instructions

**CAUTION:** To prevent risk of electric shock, remove cord plug from outlet before activating the appliance. To prevent risk of fire, inspect and clean equipment regularly as noted in this manual.

 If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

#### 1.2 Compliance with the WEEE Directive and Disposing of the Waste Product:

This product complies with EU WEEE Directive

(2012/19/EU). This product bears a classification symbol for waste electrical and electronic equipment (WEEE).



This symbol indicates that this product

shall not be disposed with other household wastes at

the end of its service

## Important Safety and Environmental Instructions

life. Used device must be returned to offical collection point for recycling of electrical and electronic devices. To find these collection systems please contact to your local authorities or retailer where the product was puchased. Each household performs important role in recovering and recycling of old appliance. Appropriate disposal of used appliance helps prevent potential negative consequences for the environment and human health.

# 1.3 Compliance with RoHS Directive

The product you have purchased complies with EU RoHS Directive (2011/65/EU). It does not contain harmful and prohibited materials specified in the Directive.

# 1.4 Package Information



Packaging materials of the product are manufactured from recyclable materials in

accordance with our National Environment Regulations. Do not dispose of the packaging materials together with the domestic or other wastes. Take them to the packaging material collection points designated by the local authorities.

# 1.5 Cleaning And Maintenance

- 1. Turn the air purifier off and unplug it before cleaning.
- 2. The outside of the air purifier can be cleaned with a soft, clean dampened cloth.
- 3. The air outlet and air inlet grill can be cleaned of dust with a small, soft brush.
- 4. If you wish to clean the inside of the air purifier, please only use a dry, soft cloth to wipe it down.
- 5. Wash the Pre-filter by following the operation described in the section of "VACUUM OR WASH THE PRE-FILTER".
- 6. Do not wash the HEPA filter.



**WARNING:** Do not allow moisture to come in contact with the body of the air purifier.

## Important Safety and Environmental Instructions

## 1.6 Vacuum Or Wash The Pre-filter

Occasionally vacuum the exterior of the fabric pre-filter to remove dust. Always unplug the unit before removing the fabric pre-filter.

- 1. Carefully rotate the body anticlockwise and remove it from the air inlet grill.
- 2. Remove the pre-filter from the HFPA filter.

- 3. Wash the pre-filter in the washing machine.
- 4. After the pre-filter is cleaned well and dried, attach the pre-filter onto the HEPA filter.
- 5. Carefully put the HEPA filter with pre-filter into the air inlet grill.
- 6. Put the body onto the air inlet grill, then rotate the body clockwise until the fastener locks into the groove.




Fig.1

## 2 How The Air Purifier Works

The air purifier removes up to 99.97% of airborne allergens as small as 0.3 microns, including ragweed pollen, grass pollen, tree pollen, household dust, dust mite debris, pet dander, smoke and odour from the air passing through the filter.

#### Know Your Air Purifier





Fig.2



## **Operating Instructions**

#### 5.1 important notes

- Carefully unpack your air purifier.
- Select a firm level place where there are no obstructions to the air inlet grill or air outlet.
- Remove all PE bags from filters before use.
- Do not point air outlet towards wall.

#### 6

#### **Controls Introduction**

#### **Power button**

Touch the Power button, the machine will start running under the default "AUTO" setting, and the indicator of "AUTO" setting will illuminate.

#### Fan speed button

There are 4 speed settings including Low, Medium, High and AUTO for selection. Touch the **Fan speed button** to select your desired speed setting.

#### Timer button

The timer allows you to run your air purifier at your convenience, for up to 8 hours. With 3 settings including 2hr, 4hr and 8hr.

#### **Dust sensor**

This Air Purifier has a built-in smart **dust sensor** which can detect the air quality of current environment automatically, and the air quality can be shown by the air quality indicator which can illuminate in blue, pink and red when the air quality is very good, good and bad accordingly.

#### Ionizer rocker switch

This appliance has an independent lonizer rocker switch equipped at the bottom of body, feature which, when turned on, releases negative ions into outgoing filtered air to help the air purification process.





Fig.4

## To Operate Your Air Purifier

- 1. Connect the appliance with power source, one "Bi" can be heard.
- 2. Touch the **Power button** once, "Bi-Bi" can be heard, the appliance starts to run under under the default "**AUTO**" setting, its corresponding indicator will illuminate, and the air quality indicator will illuminate in blue, pink or red according to the actual air quality.
- Very good air quality: The air quality indicator illuminates in blue.
- **Good air quality:** The air quality indicator illuminates in pink.
- **Bad air quality:** The air purifier illuminates in red.



**NOTE:** Hold and Touch the "**Power button**" for 2 seconds if you want to enter into the sleep mode. To recover, hold and Touch the "**Power button**" for 2 seconds again.



- 3. And you can select your required speed setting by following the operation described in "CONTROLS INTRODUCTION". After select, the corresponding indicator of selected speed setting will turn on.
- 4. After turn on the air purifier and select your required speed setting, you can activate the timer by following the operation as below: Touch down **Timer** button on the control panel, one beep "Bi" can be heard. There are 3 settings including 2H, 4H and 8H for selection. After select your required timing, the indicator of selected timing will illuminate. When the timer expires, the air purifier will power off automatically and the indicator of selected timing will extinguish.
- 5. When the filter change indicator illuminates in white, it is time to change the HEPA filter. Please change the HEPA filter by following the operation described in the section of **"CHANGE THE HEPA FILTER"**.

## 8 Change The Hepa Filter

Always unplug the unit before changing the HEPA filter.

- 1. When the filter change indicator illuminates in white, it's time to change the HEPA filter.
- 2. Turn off the unit and unplug it.
- 3. Carefully rotate the body anticlockwise and remove it from the air inlet grill.
- 4. Remove the HEPA filter out of the air inlet grill.
- 5. Remove the pre-filter.
- 6. Replace a new HEPA filter into the air inlet grill.
- 7. Put the body onto the air inlet grill, then rotate the body clockwise until the fastener locks into the groove.
- 8. Simultaneously hold and touch the Power and Fan speed buttons for 3 seconds, the indicator of replacing filter will disappear.

## 9 Troubleshooting

Problem	Solution
	□Check to make sure the unit is plugged in.
Decreased air flow.	<ul> <li>□ Check to make sure the unit is on.</li> <li>□ Check condition of the filter and replace if necessary.</li> <li>□ Check to ensure nothing is blocking the air inlet and filtered air outlet.</li> <li>□ Be sure the plastic bag has been removed from the filter.</li> </ul>

Technical and design modifications reserved.				
Made in P.R.C.				
Model No.	ATP6100I			
Power supply	100-240V~, 50-60Hz			
Rated power	21.6 W			
Contact details for obtaining more information	Beko A&NZ Pty Ltd 55 Blanck Street , Ormeau QLD, 4208 AUSTRALIA			

Parameter of External Power Supply				
Manufacturer	Debom Technology Co.,Ltd.			
Model Identifier	DBS024A-1201800A			
Input Voltage	100-240V~			
Input Frequency	50-60Hz			
Input Current	0.8A			
Output Voltage	12.0V DC			
Output Current	1.8A			
Output Power	21.6W			
Average active efficiency	88,03%			
Efficiency at low load (10%)	79,98%			
No-load power consumption	0.070W			



55 Blanck Street, Ormeau Q 4208 P O Box 354, Ormeau Q 4208 p:

5549 3146 f : 5549

ABN: 49 152 055 162

# ORIGINAL MANUFACTURER'S WARRANTY ADVICE FORM

#### **BEKO AIR PURIFIER**

#### 24 months warranty, full parts and labour warranty only.

#### **WARRANTY CONDITIONS**

The following conditions apply only in relations to the warranty expressly given on this Warranty Advice Form supplied with the product. This warranty only applies to appliances purchased and used in Australia or New Zealand and is in addition to (and does not exclude, restrict or modify in any way) other rights and remedies under a law to which the appliances relate, including any non-excludable statutory guarantees in Australia and New Zealand. It applies to the original purchaser and for appliances used in domestic applications only.

- 1. This warranty does not apply:
  - (a) if the identification number attached to the appliance has been altered, rendered illegible or removed;
  - (b) to light globes;
  - (c) to paint and vitreous enamel finishes and glass;
  - (d) to surfaces damaged by use of aerosols or cleaners;
  - (e) if the appliance has been -
    - (i) subject to misuse, abuse, negligence, accident, fire or floods;
    - connected or improper, inadequate or faulty electricity, gas, water or drainage services or intake or exhaust ducts or flues, or operated using incorrect or contaminated fuels or lubricants;
    - installed, maintained or operated otherwise than in accordance with the instructions furnished by Beko including the improper use of detergents, bleaches, cleaners or other additives;
    - (iv) damaged by foreign objects in the appliance;
    - serviced, repaired or altered otherwise than by Beko authorised service agents of Beko, or using other than Beko approved replacement parts.
- The purchaser shall be responsible for any expenses involved in making the appliances readily accessible for servicing, the purchaser shall be responsible for any costs of transporting the appliance or parts thereof to and from the nearest Beko authorised service agent.
- 3. This warranty is the only expressed warranty given by Beko.
- 4. Beko reserves the right to determine whether or not the fault is caused by faulty workmanship or material or that any part is defective.
- 5. Where permitted by law, this warranty shall not apply to loss suffered through or resulting from the non-operation or the ineffective operation of the appliance or any part of the appliance.
- 6. The purchaser must produce proof of the date of purchase together with this Warranty Advise Form when making a claim.
- Subject to your statutory rights as to the merchantable quality of the product or accessory. In the event of a product or accessory being
  replaced during the guarantee, the guarantee on the replacement will expire at the original date, i.e., 24 months from the original
  purchase date.
- 8. Australia: For Appliances and services provided by Beko in Australia, Beko goods come with a guarantee by Beko that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Appliance repaired or replaced if the Appliance fails to be of acceptable quality and the failure does not amount to a major failure. 'Acceptable quality' and 'major failure' have the same meaning as referred to in the Australian Consumer Law.
- New Zealand: For Appliances and services provided by Beko in New Zealand, the Appliances come with a guarantee by Beko
  pursuant to the provisions of the Consumer Guarantees Act, the Sales of Goods Act and the Fair Trading Act. Where the Appliance
  was purchased in New Zealand for commercial purposes the Consumer Guarantee Act does not apply.

These Warranty Conditions supersedes and excludes all other representations, conditions and warranties, except those implied by legislation previously referred to.

For Service or Spare Parts: Aust 1300 282 356 NZ 0800 692 356