

BDI1410**14 Place Setting Fully Integrated Dishwasher****Place Setting**

14

WELS Water Rating**Energy Rating****Noise Level**

47 dBA

Capacity

Number of Place Settings: 14

Design

Colour: n/a - Requires Cabinet Door

Performance

WELS Water Rating: 4 Stars

WELS Registration Number: D02267

Water Consumption: 13.8 litres

Energy Rating: 3.5 Stars

Energy Consumption: 275 kWh

Operating Noise: 47 dBA

Main Features

Program Controls: Button Control

Screen Type: White Digital LED

Progress Indicator Floor Light: Yes

Flexible Half Load Option: Yes

Time Delay Function: Yes

Tablet Detergent Function: Automatic

Electronic Rinse Aid Indicator: Yes

Number of Spray Levels: 2

Motor Type: Prosmart Inverter™

Drying System: Static

Safety:

Water Safety System: Overflow Safety

Water Leakage Indicator: Yes

Sku: 7602769077

Ean Code: 8690842213021

Manufacturers Warranty: 2 Years + 3 Years by Registration

10 Years on Inverter Motor

Launch Date: March 2019

©Beko 2021

beko.com.au / beko.co.nz

*Specifications are correct at time of printing. Specifications may change without prior notice.

Programs

Number of Programs: 6

- Intensive (70°C)
- Quick & Shine (60°C)
- Mini 30' (35°C)

Auxiliary Functions:

- Eco (45°C)
- Clean&Shine (65°C)
- Delicate (40°C)

Half Load, Super Rinse

Flexibility:

Height Adjustable Upper Rack:

3 Height Loaded Adjustable

Height Adjustable Mug Shelf:

Yes x 2

Folding Tines:

3 (Upper), 4 (Lower) Basket

Largest dish in upper basket:

25 cm

Largest dish in lower basket:

28 cm

Cutlery Basket:

Sliding

Accessories:

Knife Shelf Upper Basket

Dimensions & Weights

Unpackaged Height: 818 mm

Height (max - feet adjustment): 820-920 mm

Unpackaged Width: 598 mm

Unpackaged Depth: 550 mm

Unpackaged Weight: 32.2 kg

Packaged Height: 867 mm

Packaged Width: 657 mm

Packaged Depth: 674 mm

Packaged Weight: 37.8 kg



BDI1410

14 Place Setting Fully Integrated Dishwasher



Quick & Shine™ - Offering one of the quickest dishwasher programmes available. The Quick&Shine™ programme can wash and dry a full load of dishes, in just 58 minutes.



Intensive 70 - For the times when you've cooked up a storm. By washing at this higher temperature, more heavy soiled pots, pans and dishes are cleaned more effectively.



14 Place Setting - With the flexibility of the sliding cutlery basket, the dishwasher provides a big capacity to help you get your family load of dishes done.

Dimensions

