


BCT904IG

90 cm Induction Flexy Zone Direct Access Cooktop



Cooktop Type	Width	Burner Configuration	Display Type
Induction	90 cm	4 Zone	Direct Access

Main Features

Cooking Zones:	11 x Induction (3 flexyzones plus 2 extend zone)
Control Type:	Direct Access Touch
Construction Type:	Frameless Glass
Cooking Levels:	15 per Zone
Flexi Zones/Move Function:	Yes
Automatic Pan Detection	Yes
Total Electric Power:	9.2 kW
Fuse:	min. 16 A x 2

Control Features

Separate Controls for Each Zone	Yes
Booster Function:	Yes
Timer :	Yes
Move Function:	Yes
Stop & Go Function:	Yes
On-Off Indicator Light:	Yes
Key Lock/Cleaning Lock:	Yes

Safety

Overflow Safety Switch Off:	Yes
Overheat Safety System:	Yes
Automatic Switch Off:	Yes

Cooking Zones

Rear Left Zone:	3.6 kW (92.7 x 200 mm)
Rear Right Zone:	3.6 kW (92.7 x 200 mm)
Front Left Zone:	3.6 kW (92.7 x 200 mm)
Front Right Zone:	3.6 kW (92.7 x 200 mm)
Front Center Zone:	1.8 kW (92.7 x 200 mm)
Rear Center Zone:	3.6 kW (92.7 x 200 mm)

Dimensions & Weights

Built-in dimensions (W x D):	880 mm x 490 mm
Unpacked height:	48 mm
Unpacked width:	910 mm
Unpacked depth:	520 mm
Unpacked weight:	20.93 Kg
Packaged Height:	160 mm
Packaged Width:	980 mm
Packaged Depth:	610 mm
Packaged Weight:	23.24 Kg
For more detailed dimensions	See page 2
Sku:	7757187695
Ean Code:	8690842570360
Manufacturers Warranty:	2 Years + 3 Years by Registration
Launch Date:	November 2023



BCT904IG


90 cm Induction Flexy Zone Direct Access Cooktop



Flexy Zones/ Move Function - Make more room when you're cooking for company. The new IndyFlex+ hob has 8 zones you can use separately or combine in fours to use as 2 large units. Plus, one additional zone in the middle of the hob helps create even larger zones, with the hob automatically adjusting to match the size of your pots and pans. And with Move Function the temperature adjusts through the pan movements so you don't have to.



Direct Access Control - Giving you complete control and flexibility in the kitchen, touch controls for each cooking zone allow you to adjust the heat level of your pots and pans separately, at the simple touch of a button.



Automatic Functions - With the Automatic Functions from Beko you can choose from Fry, Simmer and Keep Warm settings, to cook all parts of your meal perfectly with just one button.

Dimensions

