

55.00 mm

Twin Tub Washing Machine

Circuit diagram

[illegible]

The schematic diagram illustrates the electrical connections for the motorized turntable. A power source is connected to a Fuse5A. A Brown wire leads to the Wash motor, and a Blue wire leads to the Spin motor. A Red wire is connected to the Wash motor, and a Gray wire is connected to the Spin motor. A Purple wire is also connected to the Spin motor. A common ground is connected to the Wash motor and the Spin motor.

Yellow/Green

■ PANTONE Cool Gray 9 C

- 1.版面光洁无污,印刷油墨不得出现漏色、褪色、挂色等现象;
- 2.文字刻板挺括,线条流畅;
- 3.印刷的图样及文字按提供的电子版图纸为准,已封样的按封样为准。

						不干胶聚酯薄膜					韩电集团宁波洗衣机有限公司				
											型号				
											铭牌				
标记	处数	更改文件号		签	Ö	日期									
设计	徐姝妮	标准化	王佳微			图样标记		重量	比例						
校对	陈佳煊	批	王玉生							1:1					
审核	曹海波														
工	黄小光	日	20.6.8			共		第							